




USO DEL RISCALDAMENTO/ARIA CONDIZIONATA

Modificare la temperatura:

1. La temperatura visualizzata sul display indica la temperatura dell'ambiente
2. Premendo le frecce (V ^) si passa alla modalità SET, ora il display indica la temperatura impostata
3. Premere le frecce (V ^) per aumentare o diminuire la temperatura impostata
4. Attendere 1 minuto circa senza più toccare il display

Spegnere/accendere il termostato:


Premere il tasto  di spegnimento/accensione (il primo a sinistra).
Se l'operazione è andata a buon fine comparirà/scompare la scritta OFF in alto a destra.

HEATING/COOLING: HOW TO USE IT

How to adjust the temperature:

1. The display temperature shows the room temperature
2. Pressing V ^ you enter in SET, now the display temperature is the one set
3. Press V ^ to increase or decrease the set temperature
4. Wait 1 minute without touching the display

How to turn on/off the thermostat:

Press the  on/off button (first on the left).
If you made it right, the word OFF will appear/disappear on the top right.